TensionLite Plus 10 ft. Curve Shape Mural Wall Design 6

TensionLite is a collection of sophisticated, ergonomically designed exhibit booths. Formulate combines state-of-the-art zipper pillowcase dye-sublimated fabric coverings with advanced lightweight aluminum structures to provide unique design, functionality, and style. The excellence of the Formulate line of displays, hanging structures and products is simply unmatched. Stretch fabric graphics are hand-sewn, durable and dry-cleanable.

features and benefits:

- State-of-the-art 30mm aluminum tube frame with snap button assembly
- Features a 34" wide counter available in four laminate color options
- Hardware mounts for a medium sized monitor, max 36"/ 40 lbs
- Design includes: one frame, one dye-sublimated pillowcase zipper graphic, stand-off monitor mount, counter, and one wheeled molded OCL and OCH2 storage case
- Lifetime hardware warranty against manufacturer defects

dimensions:

Hardware	Graphic
Assembled unit: 112.06"w x 92.574"h x 43.419"d Stand-off monitor mount with counter: 37.4"w x 92.4"h x 29.4"d Approximate weight (includes graphic): 53.5 lbs / 24.3 kgs	Total visual area: 123.125"w x 92"h Stand-off graphic total visual area: Top: 37.4"w x 24.5"h Bottom: 37.4"w x 38.2"h Please be sure to include a 2" bleed around the perimeter. Refer to related graphic template for more information.
Shipping	
Shipping dimensions - ships in two cases: One OCL case: 19"l x 19"w x 56"h One OCH2 case: 52"l x 30"w x 15"h Approximate shipping weight (with cases): 103.5 lbs / 47 kgs	

additional information:

Graphic material: dye-sublimated fabric

Countertop holds max 25 lbs / 11.3 kgs

Monitor mount: max T.V. size is 36"/ 40 lbs
*Kit does not include monitor

Table colors:

silver black mahogany natural

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

Parts Included		
Part Label	**Qty**	**Part Code**
FABRIC GRAPHIC	x1	WH10-01-G
90 DEGREE ELBOW JOINT FOR 30MM TUBING	x4	TC-30-90
T JUNCTION FOR 30MM TUBING	x6	TC-30-T
4 WAY JUNCTION FOR 30MM TUBING	x2	TC-30-X
R2000MM X 30MM TUBE (997MM ARC)	x9	WH10-01-T1
1114MM X 30MM TUBE	x8	WH10-01-T2



Parts Included		
Part Label	**Qty**	**Part Code**
30MM TUBE CLAMP	x2	ACC60
EXPANDING SPIGOT FOR 30MM TUBE	x11	ES-30
FABRIC GRAPHIC BOTTOM	x1	WL04-G-B
FABRIC GRAPHIC TOP	x1	WL04-G-T
MEDIUM MONITOR BRACKET	x1	MM-MB
881MM X 422MM X 30MM COUNTER	x1	WL04-C
30MM CURVED TUBE TOP RIGHT SIDE	x1	RWL04-T1
30MM CURVED TUBE RIGHT SIDE	x1	RWL04-T2
30MM CURVED TUBE LEFT SIDE	x1	WL04-T1
30MM CURVED TUBE LEFT SIDE	x1	WL04-T2
30MM SPREADER TUBE WITH COUNTER SUPPORTS	x1	WL04-T3
30MM BASE TUBE SECTION	x1	WL04-T4
30MM SPREADER TUBE	x1	WL05-T5
30MM TOP END SECTION	x1	WL04-T6
30MM MONITOR SUPPORT TUBE	x1	WL04-T7
PARALLEL TUBE CLAMP FOR 30MM TUBES	x2	TCP-3030



STEP 1: ASSEMBLE FRAME



Assemble top frame corners using TC-30-90. Label codes will be on backside of tube. It is best to assemble frame laying flat.



Connect top and bottom sides of frame using TC-30-T by lining up holes with snap buttons.



Use TC-30-X to connect middle frame sections; snap on button.



Frame assembly is complete once all sides and middle are connected.

STEP 2: ATTACH GRAPHIC



Slide graphic over top of frame.



Zip fabric closed as shown along bottom.



Stand unit upright.

STEP 3: ASSEMBLE LADDER FRAME

Slide joiner into tubing so hex screw sits in the hole on tubinger. Tighen hex screw so the joiner separates & tightens against the inside of the tubing, locking the joiner and tubing together.



Connect bottom and top tubes following the labels, then connect side tubes. Note tubes with velcro on face.

STEP 4: ATTACH GRAPHICS



Apply top & bottom fabric graphics to velcro on front of tubing.

STEP 5: INSTALL MONITOR MOUNT



Attach ACC60 clamps to monitor mount with a bolt and washer, tighten with wingnut.



Secure ACC60 clamps around accent tube hardware.

STEP 6: ATTACH COUNTER TO ACCENT FRAME



Use thumbscrews to attach counter to hardware.

STEP 7: ATTACH TO BACKWALL WITH CLAMPS



Position accent in front of backwall in desired location. Secure tube clamp at top of frame.



Using provided 5mm hex key, rotate bolt clockwise to secure accent to top of fabric backwall.