# TensionLite DesignerLine Lite Series 30 ft. size Display Design 4

TensionLite displays have unique stylistic features and shapes, are portable and easy to assemble. The aluminum tube frame features snap-buttons and/or spigot connections and zipper pillowcase fabric graphics. All displays come in portable, wheeled transit cases. Simply pull the pillowcase fabric graphic(s) over the frame and zip.


## features and benefi ts:

- Premium aluminum tube frames with snap button/ spigot assembly
- Vertical curved shaped frame
- Easy to store and ship
- Quick to set up
- Weighted feet for added stability
- Zipper pillowcase fabric graphic
- Lifetime limited hardware warranty against manufacturer defects

## dimensions:

| Hardware | Graphic |
|---|---|
| Assembled unit:<br>350.05”w x 91.84”h x 23.97”d<br>8891mm(w) x 2333mm(h) x 609mm(d)<br><br>Approximate weight with cases:<br>118 lbs / 53.5 kgs | Refer to related graphic template for more information. |
| Shipping | |
| Packing case(s):<br>2 OCE<br><br>Shipping dimensions:<br>41”l x 18”h x 17”d<br>1042mm(l) x 458mm(h) x 432mm(d)<br><br>Approximate total shipping weight (includes cases & graphics):<br>149 lbs / 67.6 kgs | |

## additional information:

Graphic material:
dye-sublimation zipper pillowcase fabric

# Included in Your Design

## Tools, Components, & Connectors

ALLEN KEY SET x1

TC-30-90T x2



LN114-SCRW x2

PLT-BP-WVC-STD x2

## Graphics

FMLT-DS-30-04-G x1

# Included in Your Design

Tubes

WV10-01-T1 x18



WV10-01-T2 x10

WV10-01-T4 x3



WV10-01-T5 x3

WV10-01-T6-PART C x2

WV10-01-T7 x3

WV10-01-T7-V2 x2

WV10-01-T2-L x1

WV10-01-T2-R x1

WV20-01-T1 x2



WV20-01-T2 x2

WV20-01-T7 x2

# Exploded View

## FMLT-DS-30-04



# Labeling Diagram

## FMLT-DS-30-04



# Design Assembly

## Step by Step

### Step 1.

Assemble Frame A according to the Labeling Diagram.

Please reference Connection Method 1 for more details.





### Step 2.

Apply FMLT-DS-30-04-G graphic to the frame by pulling the pillowcase over the top.

Zipper located to the bottom of the Graphic.




### Step 7.

Attach the WV10-01-T7-V2 to the backsides of the middle sections D. This component attaches with the snap button feature.

Please reference Connection Method 1 for more details.




### Step 8.

Attach the PLT-BP-WVC-STD to the outside ends of frame sections A and B. Use the provided handtool to securely fasten them onto the frame.

Setup Complete.